OUON®

HSA2000 Dual Channel Series

Handheld Spectrum User Manual

For product support, visit:www.owon.com.hk/download

*: The illustrations, interface, icons and characters in the user manual may be slightly different from the actual product. Please refer to the actual product.

Apr. 2025 edition V1.0.1

Copyright © LILLIPUT Company. All rights reserved.

The LILLIPUT's products are under the protection of the patent rights, including ones which have already obtained the patent rights and those which are applying for. The information in this manual will replace all that in the materials published originally.

The information in this manual was correct at the time of printing. However, LILLIPUT will continue to improve products and reserves the rights to change specification at any time without notice.

OWON[°] is the registered trademark of the LILLIPUT Company.

Fujian LILLIPUT Optoelectronics Technology Co., Ltd.

No. 19, Heming RoadLantian Industrial Zone, Zhangzhou 363005 P.R. ChinaTel: +86-596-2130430Web: www.owon.com.cnE-mail: info@owon.com.cn

General Warranty

We warrant that the product will be free from defects in materials and workmanship for a period of 3 years from the date of purchase of the product by the original purchaser from the our Company. The warranty period for accessories such as probes, adapter is 12 months. This warranty only applies to the original purchaser and is not transferable to a third party.

If the product proves defective during the warranty period, we will either repair the defective product without charge for parts and labour, or will provide a replacement in exchange for the defective product. Parts, modules and replacement products used by our company for warranty work may be new or reconditioned like new. All replaced parts, modules and products become the property of our company.

In order to obtain service under this warranty, the customer must notify our company of the defect before the expiration of the warranty period. Customer shall be responsible for packaging and shipping the defective product to the designated service centre, a copy of the customers proof of purchase is also required.

This warranty shall not apply to any defect, failure or damage caused by improper use or improper or inadequate maintenance and care. We shall not be obligated to furnish service under this warranty a) to repair damage resulting from attempts by personnel other than our company representatives to install, repair or service the product; b) to repair damage resulting from improper use or connection to incompatible equipment; c) to repair any damage or malfunction caused by the use of not our supplies; or d) to service a product that has been modified or integrated with other products when the effect of such modification or integration increases the time or difficulty of servicing the product.

Please contact the nearest Sales and Service Offices for services.

Excepting the after-sales services provided in this summary or the applicable warranty statements, we will not offer any guarantee for maintenance definitely declared or hinted, including but not limited to the implied guarantee for marketability and special-purpose acceptability. We should not take any responsibilities for any indirect, special or consequent damages

Table of Contents

1. Safety Information	1
Safety Terms and Symbols	1
Safety Requirements	1
2. How to Implement the General Inspection	5
3. How to Use the Oscilloscope	6
The Structure of the Oscilloscope	6
Front Panel and Keys	6
Side Panel	8
Introduction to the User Interface of the Oscilloscope	9
Functional Check	10
Probe Compensation	11
Probe Attenuation Coefficient Setting	12
Safe Use of Probe	13
Vertical System	14
Horizontal System	15
Measuring System	15
Automatic Measurement	15
Cursor Measurement	18
Display unknown signals using automatic Settings	19
Trigger System	19
Save Settings	20
System Settings	22
4. How to Use the Multimeter	25
About This Chapter	25
Instrument Interface	25
5. How to Use the Spectrum	27
About This Chapter	
Spectrum Interface	27
Parameter Input Interface	
Frequency System	29
Start Frequency	29
Stop Frequency	29
Center Frequency	30
Span	30
Full Span	31
Zero Span	31
Last Span	
Amplitude System	
Reference Level	
Scale/Div	
Attenuation	33

Reference Unit	
Reference Offset	34
Bandwidth System	35
RBW	35
VBW	35
Marker System	
Marker	
Marker Function	37
Marker->	
Peak	
Trigger System	39
Auto	40
Video	40
Pre-amplifier	40
Automatic Research	40
6. Communication with PC	41
7. Troubleshooting	
8. Technical Specifications	
Oscilloscope	
Multimeter	46
Spectrum	
General Technical Specifications	50
9. Appendix	51
Appendix A: List of Accessories	
Appendix B: Maintenance and Cleaning	51
General maintenance	51
Charging and Replacement of Battery	
Replacement of Lithium Battery	53

1. Safety Information

(Before using this product, please read the safety information in advance)

Safety Terms and Symbols

Terms in this manual

The following terms may appear in this manual:



Warning: Warning indicates conditions or practices that could result in injury or loss of life.



Caution: Caution indicates the conditions or practices that could result in damage to this product or other property.

Terms on the product

The following terms may appear on this product:

Danger: Indicates an immediate hazard or injury possibility.

Warning: Indicates a possible hazard or injury.

Caution: Indicates potential damage to the instrument or other property.

Safety Symbols

Symbols on the product. The following symbol may appear on the product:



Hazardous Voltage



Refer to Manual



Protective Earth Terminal



Chassis Ground

Test Ground

Safety Requirements

Please read the following safety precautions to avoid personal injury and

prevent damage to this product or any other products connected to it. In order to avoid possible hazards, this product can only be used within the specified range.

Only a qualified person should perform internal maintenance.

- Check all Terminal Ratings. To avoid fire or shock hazard, check all ratings and markings on this product. Refer to the user manual for more information about ratings before connecting to the instrument.
- **Do not operate without covers**. Do not operate the instrument with covers or panels removed.
- Avoid exposed circuit. Be careful when working on exposed circuitry to avoid risk of electric shock or other injury.
- Do not operate if any damage. If you suspect damage to the instrument, have it inspected by qualified service personnel before further use.
- Do not operate in damp conditions.
- Do not operate in an explosive atmosphere.
- Keep product surfaces clean and dry.
- Using the equipment not in accordance with the method specified by the manufacturer may damage the protection provided by the equipment.

Marning:


To prevent electric shock or fire, use a suitable power adapter. Only power adapters that are dedicated to this product and approved for use in the country of use may be used.

Marning:


The two channels of the oscilloscope are non-isolated channels. Note that the channel should use a common reference when measuring, and the ground wires of the two probes cannot be connected to two non-isolated places with different DC electrical levels, otherwise it may cause a short circuit due to the ground wire connection of the oscilloscope probe.

Marning:

Note that the channel should use a common reference when measuring, otherwise it may cause a short circuit due to the ground wire connection of the oscilloscope probe. Schematic diagram of the internal ground wire connection of the oscilloscope:



Schematic diagram of internal ground connection when oscilloscope is connected with computer through the port:



When the oscilloscope is AC powered by adapter or connected with AC powered computer through the port, it is not allowed to measure the primary power supply of power grid.

Marning:

If the input port of the oscilloscope is connected to a voltage with a peak value higher than 42V (30vrms) or a circuit with a peak value of more than 4800 VA, the following measures shall be taken to avoid electric shock or fire:

- Only voltage probes, test wires and adapters with proper insulation attached to the oscilloscope or accessories suitable for oscilloscope instrument series products specified by our company shall be used.
- Before use, check the multimeter test probe, oscilloscope probe and accessories for mechanical damage. If damage available, replace it.
- Remove all unused multimeter test probes, oscilloscope probes and accessories (power adapter, USB, etc.).
- Firstly, plug the power adapter into the AC socket, and then connect it to the oscilloscope.
- When testing in a CAT II environment, do not connect a voltage higher than 400 V to any input port.
- When testing in a CAT II environment, do not connect a voltage with a voltage difference of more than 400 V to the isolated input port.

- Do not use an input voltage higher than the rated value of the instrument.
 Pay special attention when using 1:1 test wires, because the probe voltage will be directly transmitted to the oscilloscope.
- Do not touch the bare metal BNC or banana plug.
- Do not insert metal objects into the connector.
- Use the oscilloscope only in the specified way.
- The voltage rating mentioned in the "warning" information is the limited value of "working voltage". They represent V ac rms (50-60 Hz) in AC sine wave applications; and V dc in DC applications. CAT is the prefix, and II refers to the level. Level II is the low voltage and high energy level, which refers to the local electrical level applicable to electrical appliances and portable equipment.

2. How to Implement the General Inspection

After you get a new oscilloscope, it is recommended that you should make a check on the instrument according to the following steps:

(1) Check whether there is any damage caused by transportation.

If it is found that the packaging carton or the foamed plastic protection cushion has suffered serious damage, do not throw it away first till the complete device and its accessories succeed in the electrical and mechanical property tests.

(2) Check the Accessories

The supplied accessories have been already described in the "Appendix A: List of Accessories" of this Manual. You can check whether there is any loss of accessories with reference to this description. If it is found that there is any accessory lost or damaged, please get in touch with our distributor responsible for this service or our local offices.

(3) Check the Complete Instrument

If it is found that there is damage to the appearance of the instrument, or the instrument can not work normally, or fails in the performance test, please get in touch with our distributor responsible for this business or our local offices. If there is damage to the instrument caused by the transportation, please keep the package. With the transportation department or our distributor responsible for this business informed about it, a repairing or replacement of the instrument will be arranged by us.

3. How to Use the Oscilloscope

The Structure of the Oscilloscope

Front Panel and Keys

The front panel and keys of the oscilloscope are shown in Figure 3-1:




Figure 3-1: Front Panel of the Oscilloscope

Description:

- 1. CH1 and CH2 input connectors.
- 2. Spectrum measured signal input connector..
- 3. Display area.
- 4. The **F1 F4** keys are multi-function keys. In each menu mode, press the corresponding key to select the corresponding menu item.
- 5. After pressing the HOR key, through the key ▲ ▼, you can change the horizontal time base setting, and observe the change of the state information caused by it; it can also be found that the horizontal time base display corresponding to the status bar has changed correspondingly; the horizontal displacement of the signal in the waveform window can be adjusted by pressing <>.
- 6. Return key. Press this key to return to the previous menu; when the menu is the first level, press the return key to close the menu.
- Measurement menu key (oscilloscope), range key (multimeter) or reset key(spectrum).
- 8. Zoom or move key:

Function of direction keys \checkmark : used for the up and down movements of waveform, the time base changing, the voltage cursor movements and the trigger of electrical level change in the oscilloscope;

Function of direction keys : used for the left and right movements of waveform, the voltage position changing and the movements of time cursor in the oscilloscope.

- 9. Automatic setting key (oscilloscope), automatic range key (multimeter), or automatic search key(spectrum).
- 10. Stop / run key (oscilloscope) or value hold key (multimeter) or output/disable signal key(spectrum).
- 11. Input end of the multimeter.
- 12. Trigger menu key (oscilloscope), relative value key (multimeter) or select

the numeric key(spectrum).

- 13. \bigcup_{i} Power switch key.
- 14. Enter the save settings key.
- 15. Enter the system settings key.
- 16. Switch key for working state of oscilloscope and multimeter.
- 17. CH1 / CH2 channel switch key.

Side Panel



Figure 3-2: Side Panel of the Oscilloscope

Description:

- 1. Probe compensation: 3.3V/1kHz square wave signal output.
- 2. Charging or USB communication interface.
- 3. Bracket.

Introduction to the User Interface of the Oscilloscope




Figure 3-3:Oscilloscope Interface

Description:

1. The trigger status indicates the following information:

Auto: Automatic mode. The waveform is being collected without triggering.

Trig: A trigger has been detected and post trigger information is being collected.

Ready: All pre trigger data have been obtained and the oscilloscope is ready.

Scan: Scan mode. Continuously collect and display waveform data.

Stop: Stop collecting waveform data.

- 2. Run/stop.
- 3. Time base display.
- 4. The pointer indicates the trigger horizontal position.
- 5. The pointer indicates the trigger position within the current storage depth.
- 6. Indicating the value of the current trigger horizontal displacement, and displaying the position of the current waveform window in the memory.

- 7. It indicates that there is a USB disk connecting.
- 8. Battery power and external power supply indication.
- 9. Channel 1 waveform.
- 10. The pointer indicates the trigger electrical level position of the channel.
- 11. Channel 2 waveform.
- 12. The icon indicates trigger-related information, including trigger channel, coupling mode, trigger type and trigger electrical level. For details, please refer to P19 Trigger System.
- 13. The current sampling rate.
- 14. The channel information reading indicates the voltage position of the corresponding channel.
 - The icon indicates the coupling mode of the channel:
 - "—" means DC coupling;
 - " \sim " means AC coupling;
 - " \pm " means ground coupling.
- 15. The pointer indicates the grounding reference point (zero position) of the waveform displayed in CH2 channel. If there is no pointer indicating the channel, it means that the channel is not open.
- 16. The pointer indicates the grounding reference point (zero position) of the waveform displayed in CH1 channel. If there is no pointer indicating the channel, it means that the channel is not open.
- 17. Waveform display area.

Functional Check

Making a quick functional check to verify that the instrument is working properly. Please proceed as follows:

1. Press the switch at the bottom left of the main unit 🕛.

The internal relay will make a slight click. The instrument executes all self-check items, and the startup screen appears. Press the front panel key

System, the default probe menu attenuation coefficient setting value is 10X.

2. The switch on the oscilloscope probe is set to 10X and connected with the CH1 channel.

Align the slot on the probe with the plug on the bayonet nut connector (**BNC**) of the **CH1** connector and insert it, then turn the probe to the right and tighten it.

Connect the probe tip and ground clamp to the connector of the probe compensator. Please pay attention to the terminal polarity. The square terminal represents the signal output, and the round terminal represents the reference ground.

3. Press the "Auto" key on the front panel.

Within a few seconds, a square wave display (1kHz/3.3Vpp) can be seen, as shown in Figure 3-4.




Figure 3-4: Automatic Setting Repeat steps 2 and 3 on the CH2 channel.


Probe Compensation

When connecting the probe to any input channel for the first time, make this adjustment to match the probe with the input channel. The probe without compensation or deviation compensation will lead to measurement error. To adjust the probe compensation, please follow the following steps:

1. Set the probe menu attenuation coefficient to **10X**, and set the switch on the

probe to **10X** (see "Probe Attenuation Coefficient Setting" in P9), and connect with CH1. If a hook probe is used, make sure it is in close contact with the probe. Connect the probe tip to the signal output connector of the probe compensator, and connect the reference wire clamp to the ground wire connector of the probe compensator, and then press the **Auto** key on the front panel.

2. Check the displayed waveform and adjust the probe until the compensation is correct. See Figure 3-5 and Figure 3-6.



Overcompensation Correct compensation Under-compensation Figure 3-5: Display Waveform of Probe Compensation

3. Repeat the steps if necessary.




Figure 3-6: Probe Adjustment

Probe Attenuation Coefficient Setting

The probe has a variety of attenuation coefficients, which will affect the vertical position factor of the oscilloscope.

To change (check) the set value of probe attenuation coefficient in the oscilloscope menu, please follow the steps below:

- (1) Press the CH1/CH2 key to switch the channel to be used.
- (2) Press the F3 to select the desired attenuation coefficient. This setting is

valid until it is changed again.

Note: The preset setting of the probe attenuation coefficient in the menu when the oscilloscope is delivered is 10X. Make sure that the attenuation switch setting value on the probe is the same as the probe attenuation coefficient option in the oscilloscope menu.

The setting value of the probe switch is **1X** and **10X**. See Figure 3-7.



Figure 3-7: Probe Attenuation Switch



Note: When the attenuation switch is set to **1X**, the probe limits the bandwidth of the oscilloscope to **5 MHz**. To use the full bandwidth of the oscilloscope, be sure to set the switch to **10X**.

Safe Use of Probe

The safety ring surrounding the probe body provides a barrier to protect the fingers from electric shocks. See Figure 3-8.



Figure 3-8: Finger Safety Ring of the Probe

Warning: To prevent electric shock when using the probe, please keep your fingers behind the safety ring on the probe body.
To prevent electric shock when using the probe, do not touch the metal part of the probe head when the probe is connected to a voltage source.

Before making any measurements, connect the probe to the instrument and connect the ground terminal to the ground.

Vertical System

The vertical system can be used to adjust the vertical scale, the position and other settings of the channel. Each channel has a separate vertical menu, which can be set individually for each channel.

Vertical position

Press the **CH1/CH2** keys to select the channel, and move the vertical position of the selected channel up or down by pressing the \blacktriangle or \checkmark direction keys. Press the \blacktriangle and \checkmark direction keys at the same time to center the vertical position.

Vertical Volt/Div Setting

The volt/div range is 10mV/div-10V/div (probe 1X), stepping in the 1-2-5 way, or 100mV/div-100V/div (probe 10X), 1V/div-1000V/div (probe 100X),

10V/div-10000V/div (probe 1000X), 100V/div-100000V/div (probe 10000X).

Press the CH1/CH2 key to select the channel, and press the < or >

direction key to change the volts/div setting of the selected channel.

The description of the vertical system setting menu is as follows:

Function menu	Setting	Description
Switch	ON	Turn on the waveform display.
	OFF	Turn off the waveform display.
Coupling	DC AC GND	The normal sampling method uses the AC and DC components of the input signal. Block the DC component of the input signal. Disconnect the input signal.
Probe	1X 10X 100X 1000X 10000X	Choose one of the values according to the probe attenuation factor to keep the vertical scale reading accurate.
Bandwidth	20MHz Full band	Limit the bandwidth to 20MHz to reduce display noise.

Horizontal System

Press the **HOR** key to enter the horizontal system setting menu. Use the ◀ and ➤ direction keys to change the horizontal scale (time base) and horizontal trigger position. When changing the horizontal scale, the waveform is enlarged or reduced relative to the center of the screen. When the horizontal position changes, the position relative to the waveform trigger point changes. **Note**: Press the ◀ and ➤ direction keys at the same time to center the horizontal position.

Function menu	Setting	Description
	Sample	Normal sampling method.
Acqu Mode	Peak Detect	Used to detect interference glitches and reduce the possibility of confusion.
Length	4K 8K	Select the length to be recorded.
XY Mode	ON OFF	Choose to turn XY mode on or off.
1/2		Enter the next menu.
Refresh	High Low	Set the refresh rate to "High" or "Low".
Hor center		Set the horizontal trigger position in the middle of the screen.
Counter	ON OFF	Turn on/off counter.
2/2		Return to the previous menu.

The description of the horizontal system setting menu is as follows:

Measuring System

Automatic Measurement

Measure

Press Range and F1 key to realize automatic measurement. There are up to

9 types of measurement can be displayed at the bottom left of the screen.

For bandwidth ≤100MHz models, automatic range types include Frequency,

Period, Amplitude, Maximum, Minimum, Peak-to-Peak value, Mean, and

RMS.


For bandwidth **200MHz** models, automatic range types include Frequency, Period, Amplitude, Maximum, Minimum, Peak-to-Peak value, Mean, RMS, Rise Time, Fall Time, +PulseWidth, -PulseWidth.

Function Menu			Description
		ON OFF	Turn automatic measurement on or off.
	Source	CH1 CH2	Set the source.
Measure	Add Del	Freq (F) Period (T) Amp (Va) Min (Mi) Max (Ma) PK - PK (Vpp) Mean(V) RMS (RMS) Rise Time (RT) Fall Time (FT) +PulseWidth (PW) -PulseWidth (NW)	Add or delete the selected measurement type (displayed in the lower left corner, up to 9 types). Note: The unselected state is □; The selected state is ■.

The description of the automatic measurement **Function Menu** is as follows:

The automatic measurement of voltage parameters

The oscilloscopes provide automatic voltage measurements including Mean, PK-PK, RMS, Max, Min and Vamp. Figure 3-9 below shows a pulse with some of the voltage measurement points.





Mean: The arithmetic mean over the entire waveform.

PK-PK: Peak-to-Peak Voltage.

RMS: The true Root Mean Square voltage over the entire waveform.

- Max: The maximum amplitude. The most positive peak voltage measured over the entire waveform.
- Min: The minimum amplitude. The most negative peak voltage measured over the entire waveform.

Vamp: Voltage between Vtop and Vbase of a waveform.

The automatic measurement of time parameters

The oscilloscopes provide time parameters auto-measurements include Period, Frequency, Rise Time, Fall Time, +D width and -D width.




Figure 3-10

- Rise Time: Time that the leading edge of the first pulse in the waveform takes to rise from 10% to 90% of its amplitude.
- Fall Time: Time that the falling edge of the first pulse in the waveform takes to fall from 90% to 10% of its amplitude.

+D width: The width of the first positive pulse in 50% amplitude points.

-D width: The width of the first negative pulse in the 50% amplitude points.

Cursor Measurement

 $\frac{Measure}{Range} \text{ and } F2 \text{ key to realize cursor measurement.}$

The description of **Cursor Measurement Menu** is as follows:

Function Menu	Setting	Description
	CH1 Voltage	Select to display the CH1 voltage measurement
		cursor and menu.
Туре	CH2 Voltage	Select to display the CH2 voltage measurement cursor and menu.
Type	Time	Select to display the time measurement cursor and
		menu.
	None	Turn off the cursor measurement.
		When the type is selected as CH1 Voltage or CH2
		Voltage , press the arrow keys ▲ ▼ to move the
А		cursor line A; when the type is selected as Time ,
		press the arrow keys \blacktriangleleft > to move the cursor
		line a.
		When the type is selected as CH1 Voltage or CH2
		Voltage , press the arrow keys \checkmark \checkmark to move the
В		cursor line B; when the type is selected as Time ,
		press the arrow keys◀ ➤ to move the cursor line
		b.
		Link A and B. When the type is selected as CH1 or
		CH2, by pressing the arrow keys ▲ ▼two cursors
AB		can be moved at the same time; when the type is
		selected as Time , by pressing the arrow keys
		, two cursors can be moved at the same time.

Display unknown signals using automatic Settings

The automatic setting function enables the oscilloscope to automatically display and measure unknown signals. This function optimizes position, range, timebase, and trigger and ensures a stable display of any waveform. This feature is particularly useful for quickly checking several signals. To enable auto-setup, perform the following steps:

- 1. Connect the oscilloscope probe to the measured signal.
- 2. Press the Auto key, the oscilloscope enters the automatic measurement state, and the measured signal will be displayed on the screen.

Trigger System

The trigger determines when the oscilloscope starts to acquire data and display waveforms. Once the trigger is set correctly, it can convert an unstable display into a meaningful waveform.

When the oscilloscope starts to acquire data, it first acquires enough data to draw the waveform on the left side of the trigger point. The oscilloscope continuously acquires data while waiting for the trigger condition to occur. When a trigger is detected, the oscilloscope continuously acquires enough data to draw a waveform on the right of the trigger point.

The trigger mode of this series of oscilloscopes is edge trigger.

The edge trigger mode is to trigger on the trigger electrical level of the edge of the input signal, that is, trigger on the rising and falling edges of the input signal.

Entering the edge trigger, the trigger setting information is displayed at the bottom right corner of the screen, e.g. CH1:DC **F** -20.0mV. It indicates that the trigger type is rising edge, the trigger source is CH1, the trigger coupling is DC, and the trigger electrical level is -20.0mV.

The description of the trigger system setting menu is as follows:

Function Menu	Setting	Description
Source	CH1	Set Channel 1 as the source trigger signal.
Source	CH2	Set Channel 2 as the source trigger signal.
	AC	Set to prevent DC component from passing
Coupling	DC	through.
		Set to allow all components to pass through.
	Auto	Waveforms can be acquired without detecting
		trigger conditions.
Туре	Normal	The waveform is acquired only when the trigger
1900		conditions are met.
	Single	When a trigger is detected, a waveform is sampled
		and then stopped.
1/2		Enter the next menu.
Slana	Rising edge	Trigger on the rising edge of the signal.
Slope	Falling edge	Trigger on the falling edge of the signal.
Trigger		The trigger position is set in the middle of the
center		waveform.
		Forced trigger key, which forcibly generates a
Force		trigger signal, mainly used in the "normal" and
		"single" modes of the trigger mode.
2/2		Return to the previous menu.

Trigger electrical level: The amplitude level that the signal must cross when setting the waveform acquisition. Press the **Trig**/ \triangle key to enter the trigger menu, and press the \blacktriangle or \forall key to move the trigger electrical level up and down.

Save Settings

Press the **Save** key to enter the save function menu. By operating the save function menu, oscilloscope settings, reference waveforms, and files can be stored.

• Configure

Any setting can be saved inside the oscilloscope, and restore settings can also be called.

The description of **Configure** menu is as follows:

Function Menu	Setting	Description
Object	S1 S2 S3 S4	Set waveform name.
Save		Save the current parameter settings of the oscilloscope to the internal memory.
Recall		Call the settings saved in the current storage location.

• Reference Waveform

The actual waveform can be compared with the reference waveform to find out the difference. Press the **Save** key to enter the save function menu, and press **F2** to select the reference waveform to enter the reference waveform menu.

Function Menu	Setting	Description
Source	CH1 CH2	Select the reference waveform to be saved.
Object	R1 R2 R3 R4	Set waveform name.
Display	ON OFF	Call or close the waveform of the current target address in the internal memory. When it displays "On", if there is a stored waveform at the current address, the waveform will be displayed, and the address number and waveform related information will be displayed in the upper left corner; if the current address is not stored, it will display "Address No.: No waveform saved".
Save		Save the reference waveform of the source to the memory.

The description of the Reference Waveform menu is as follows:

• File

The file can be saved as waveform or image. The waveform and image can be read by plugging and unplugging the USB data cable or selecting MSC in the USB option on the next page of system settings. The description of **File** menu is as follows:

Function Menu	Setting		J	Description
		File name	wave1 wave2 wave3 wave4 CH1	Select the file name of the stored waveform.
	Wave	Source	CH1 CH2	saved.
File		Save		Store the waveform of the source in a csv file named by the specified file name.
	nan Image	File name	image1 image2 image3 image4	Select the file name of the stored wave image.
		Save		Store the current screen image in the bmp file named by the specified file name.

System Settings

Press the **System** key to enter the system function menu.

• Display

The description of the menu is as follows:

Function Menu	Setting	Description
Brightness	10% - 100%	Set the screen backlight to increase in a 10% cycle.
	30s	
Backlight	60s	Set the screen backlight luminance time.
time	120s	Unlimited means always on.
	Unlimited	
	5s	
	10s	
Menu Time	20s	Set the menu display time.
	30s	
	60s	
Turned on	00h: 00m	Display how long it has been powered on.

• System

The description of the menu is as follows:

Function Menu	Setting	Description
Language		Set the menu language.
Shutdown Time	10 min 30 min 60 min Unlimited	Set the automatic shutdown time. Unlimited means no shutdown. Please pay attention to this setting if you use the battery only.
1/2		Enter the next menu
About		After pressing this key, the instrument model, serial number, version, and checksum can be displayed.
Upgrade		To upgrade the system. The version of the upgrade package must be higher than the version of the instrument itself.
2/2		Return to the previous menu

• Default setting

Press the **System** key to enter the system setting menu. Select **F3** "Default setting", the screen will prompt "Press < F3 >for default setting Otherwise press the Return key". If you need to perform the default setting, press F3 again to complete the default setting, otherwise, press the return key.

USB Connection

Press the **System** key to enter the system setting menu. Select **F4** to enter the next page. Press **F1** to select **HID** or **MSC**.

1) **MSC [Mass Storage Class]** is used to make USB read the files stored in the built-in memory.

2) **HID [Human interface Device]** is used to select the oscilloscope device as the host computer to control and communicate with the computer.

• Factory Settings

To set the factory settings, press the **System** key. Press the menu selection key **F4** to enter the next page. Select **F2** "Factory setting", the screen will prompt "Press < F2 >for factory setting Otherwise press the Return key". If you need to perform the factory setting, press F2 again to complete the factory setting, otherwise, press the return key.

• Automatic Calibration

The automatic correction program can quickly make the oscilloscope reach the best condition to obtain the most accurate measurement value. You can execute this program at any time, but if the ambient temperature variation range reaches or exceeds 5° , you must execute this program.

To perform automatic correction, disconnect all probes or wires from the input connector. Then, press the **System** key. Press the menu selection key **F4** to enter the next page, select **F3** "Auto calibration", the screen will prompt "Disconnect all inputs Press < F3 >to execute auto calibration Otherwise press the Return key". If you need to perform the auto calibration, please disconnect all inputs, perform automatic correction after confirming readiness.

4. How to Use the Multimeter


About This Chapter

This chapter introduces the multimeter function of the oscilloscope step by step, and provides some basic examples of basic operations and how to use the menu.

Instrument Interface

The multimeter uses four 4-mm safety banana plug input ends: **A**, **mA**, **COM**, **and** $V\Omega \rightarrow C$.

Multimeter interface:



Description:

1. Measurement type indication:

	 DC voltage measurement
$\sim \rm ACV$	 AC voltage measurement
DCA	 DC current measurement
\sim ACA	 AC current measurement

Ω Resist	 Resistance measurement
╊ Diode	 Diode measurement
() Cont	 On/Off measurement
- ⊱ Cap	 Capacitance measurement

2.Range indication: **Manual** means manual range; **Auto** means automatic range.

- 3. Current measurement range.
- 4. Indicating that there is a USB cable inserted.
- 5. Battery power indication.
- 6. "Hold" can keep the current reading on the display.
- 7. Measurement value and unit.
- 8. Display of switching resistance, buzzer, diode and capacitance

measurement function.

9. The selected range V or mV in voltage measurement; the selected current range A or mA in current measurement.

- 10. To choose AC or DC current measurement.
- 11. To choose to AC or DC voltage measurement.

12. Display of relative value measurement function (only available when measuring DC current, DC voltage and resistance).


5. How to Use the Spectrum


About This Chapter

This chapter introduces the spectrum function of the oscilloscope step by step, and provides some basic examples of basic operations and how to use the menu.

Spectrum Interface

Press the **Mode** key to switch to the spectrum interface, as shown in the image below.





Description:

- 1. Reference level.
- 2. Attenuator.
- 3. Scale/Div.
- 4. Bandwidth.
- 5. Indicating that there is a USB cable inserted.
- 6. Battery power indication.
- 7. Marker.

- 8. Waveform display area.
- 9. Stop frequency.
- 10. Center frequency.
- 11. Start frequency.
- 12. Marker parameter.
- 13. Amplitude scale.

Parameter Input Interface

Parameter input is modified using the numeric keypad, Trig/ \triangle button, and directional keys, as shown in the image below.




Figure 5-2 Numeric keypad interface

Description:

- 2. <- (back button: During the parameter input process, use < ➤ to move to < -,and press the **Trig/△** button to delete characters from right to left.
- 3. Unit buttons: Press the required unit button after inputting numbers, use
 ✓ ➤ to select the appropriate unit and press the Trig/△ button to complete the input.

- Numeric keys: Press keys 0-9 to select, use the → button to move the selection, and press Trig/△ to confirm the input of the parameter value.

Frequency System

The frequency menu can be accessed in the following two ways.

- Press F1 to display the spectrum menu, and then press F1 to select frequency to enter the frequency menu.
- Press **CH1/2** to enter the frequency menu directly.

Start Frequency

Press the **F1** key to activate the start frequency.

Note:

- The span and center frequency are changed automatically according to the start frequency. The change of the span would have influence on other system parameters. For more details, please refer to "Span".
- In Zero Span mode, the start frequency, stop frequency and center frequency are always equal. If one is changed the others are updated to match.
- You can modify this parameter using the numeric keys, Trig/△, or direction keys.
- If start freq is larger than stop freq when setting, then stop freq will increase automatically to the same value of start freq.

Stop Frequency

Press the F2 key to activate the stop frequency.

Note:

- Modifying the stop frequency changes the span and center frequency, and the change of span influences other system parameters, see "Span".
- You can modify this parameter using the numeric keys, Trig/△, or direction keys.
- If stop freq is larger than start freq when setting, then start freq will decrease automatically to the same value of stop freq.

Center Frequency

Press the **F3** key to activate the center frequency. If the set center frequency and the current sweep width are not compatible, the sweep width will automatically adjust to the optimal value that corresponds to the desired frequency.

Note:

- Modify the center frequency will automatically adjust the starting and ending frequencies while keeping the sweep width setting unchanged.
- Chang the center frequency is equivalent to shifting the current channel.
 The adjustable range is limited by the frequency range specified by the indicator.
- In zero sweep width mode, the values of the starting frequency, ending frequency, and center frequency are the same and will be modified together.
- You can modify this parameter using the numeric keys, Trig/△, or direction keys.

Span

Press the **F4** key to enter the next page of the menu. Press the **F1** key to select the sweep width and set the frequency range for the current channel. Pressing this key will switch the frequency input mode to: Center Frequency / Sweep Width.

Note:

- The start and stop frequencies are changed with the span automatically.
- In non-zero span mode, the span can be set down to 100 Hz. And up to the full span described in "Specification". When it is set to the maximum span, it enters full span mode.
- In non-zero sweep width mode, changing the sweep width will automatically adjust the frequency step size and resolution bandwidth if they are set to auto mode. Any change in the resolution bandwidth will cause a change in the video bandwidth (when in auto mode).
- Any change in sweep width, resolution bandwidth, or video bandwidth will result in a change in the scan time.
- You can modify this parameter using the numeric keys, Trig/△, or direction keys.

Full Span

Press the **F4** key to enter the next page of the menu. Press the **F2** key to select the full sweep width. Pressing this key will switch the frequency input mode to: Center Frequency / Sweep Width mode, and set the sweep width to the maximum value.

Zero Span

Press the **F4** key to enter the next page of the menu. Press the **F3** key to select zero sweep width. This will set the sweep width to 0, at which point both the starting and ending frequencies will be equal to the center frequency, and the horizontal axis will represent time. In this mode, the instrument measures the time-domain characteristics of the amplitude at the frequency point corresponding to the input signal. This is useful for observing signals in the time domain, particularly for observing modulated signals.

Last Span

Press the **F4** key to enter the next page of the menu. Press the **F4** key again to select Last Span. This will return the instrument to the sweep width previously selected.

Amplitude System

The amplitude menu can be accessed in the following two ways.

- Press F1 to display the spectrum menu, and then press F2 to select amplitude to enter the frequency menu.
- Press **HOR** to enter the amplitude menu directly.

Reference Level

Press the **F1** key to activate the reference level. This allows you to set the maximum power or voltage value that can be displayed in the current window. Note:

This value is affected by a combination of maximum mixing level, input attenuation, and preamplifier. When you adjust it, the input attenuation is adjusted under a constant max mixing level, meeting:

 $L_{Ref} - a_{RF} + a_{PA} \leq L_{mix}$

 L_{Ref} , a_{RF} , a_{PA} and L_{mix} denotes the reference level, the input attenuation, the preamplifier, and the max mixing level respectively.

• You can modify this parameter using the direction keys.

Reference level located at the top of axis grid. Measurement near the reference level would gain better accuracy, but input signal amplitude should not exceed the reference level; if it exceeds, the signal will be compressed and distorted, result in wrong measurement. Analyzer's input attenuation is related with reference level, it can self-adjust to avoid signal compression. Minimum reference level is -80dBm at Log scale under 0dB attenuation.

Scale/Div

Press the **F2** key to activate the Scale/Div function. This allows you to set the size of each vertical grid unit. This feature is only available when the scale type is set to logarithmic. You can choose from 1, 2, 5, or 10 dB per grid unit. The default value is 10 dB per grid. Once activated, any frequency markers displayed will show readings in dB, and the difference between two frequency markers will also be displayed in dB.

Note:

- By changing the scale, the displayed amplitude range is adjusted.
- The amplitude that can be displayed is from reference level minus 10 times the current scale value to the reference level.
- You can modify this parameter using the direction keys.

Attenuation

Press the **F3** key to activate the Center Frequency function. If the set center frequency is not compatible with the current sweep width, the sweep width will adjust the RF front-end attenuator to ensure that large signals can pass through the mixer with low distortion (and small signals with low noise). This function is only valid in Internal Mixing Mode , and it is used to adjust the input attenuator of the spectrum analyzer. In Auto Mode, the input attenuator is associated with the reference level. Note:

- When the pre-amplifier is activated, the maximum input attenuation can be set to 30 dB. If the set parameters do not meet the requirements, the system will ensure the proper operation by adjusting the reference level.
- When the reference level is changed, the attenuation value can be automatically adjusted. However, changing the attenuation does not affect the reference level itself.
- You can modify this parameter using the direction keys.

The purpose of adjusting the attenuator is to ensure that the maximum signal amplitude entering the input mixer is less than or equal to -10 dBm. For example, if the reference level is +12 dBm and the attenuation is 22 dB, the input level to the mixer will be -18 dBm (12 - 22 - 8 = -18), with the ultimate goal of preventing signal compression.

You can select [Attenuator Auto Manual] by pressing the **F3** key to set the attenuator to Manual Mode for manual adjustment. The highlighted line under Auto or Manual indicates whether the attenuator is in Auto Coupling Mode or Manual Mode.

When the attenuator is in Manual Mode, press the **F3** key and select [Attenuator Auto Manual] to re-link the attenuator to the reference level.

Note: Maximum input signal amplitude of input attenuator (10dB input attenuation at least) is +27dBm, higher power signal will damage input attenuator or mixer.

Reference Unit

Press the F4 key to enter the next menu page, then press the F1 key to select

the reference unit and set the unit for the current channel, including: [dBm],

[dBmV], [dB μ V], [W] and [V] $_{\circ}$

Note:

• [dBm]

Choose decibel equals to 1mW as amplitude unit.

• [dBmV]

Choose decibel equals to 1mV as amplitude unit.

• [dBµV]

Choose decibel equals to $1\mu V$ as amplitude unit.

• [W]

Choose Watts as amplitude unit.

• [V]

Choose Voltage as amplitude unit.

Reference Offset

Press the **F4** key to enter the next menu page, then press the **F2** key to activate the reference offset. When there is gain or loss between the device under test and the spectrum analyzer input, an offset value is added to the reference level to compensate for the gain or loss. Note:

- This value does not change the position of the curve, it only modifies the amplitude reading of the reference level and the cursor.
- You can modify this parameter using the direction keys.
- This offset use dB as absolute unit, will not change with selected scale

and unit.

Bandwidth System

Press the **F1** key to display the spectrum menu, then press the **F3** key to select bandwidth, which will enter the bandwidth menu.

RBW

Press the **F1** key to select the resolution bandwidth. Use the arrow keys to change the resolution bandwidth value. Press the **F1** key again to toggle the resolution bandwidth between auto mode and manual mode. Note:

- Reducing the value of RBW will increase the frequency resolution, but may also cause sweeps to take longer (Sweep Time is effected by a combination of RBW and VBW when it is in Auto mode).
- RBW decreases with the span (non-zero span) in Auto RBW mode.

VBW

Press the **F2** key to select the video bandwidth. Use the arrow keys to change the video bandwidth value. Press the **F2** key again to toggle the video bandwidth between auto mode and manual mode.

Note:

- Reducing the VBW to smooth the spectrum line and differentiate small signals from the noise. However, this may cause a longer sweep time.
 (Sweep Time is effected by a combination of RBW and VBW when it is in Auto mode).
- VBW varies with RBW when it is set to Auto.

Marker System

Press the **F1** key to display the spectrum menu, then press the **F4** key to enter the next menu page. After that, press the **F1** key again to select the frequency marker, which will enter the frequency marker menu.

Marker

Press the **F1** key to enter the frequency marker submenu. Use the left and right arrow keys to select the current frequency marker.

(1) Press the **F1** key to select the frequency marker type as Normal.

In normal measurement mode, activate the cursor to measure the X (frequency or time) and Y (amplitude) values at a specific point on the trace. After selecting Normal mode, a cursor labeled with the current cursor number, such as "1" will appear on the trace.

Note:

- If no active marker exists currently, a one will be enabled automatically at the center frequency of current trace.
- You can use the direction keys to move the marker. The readouts of the marker will be displayed on the corner left of the screen.
- The readout resolution of the X-axis corresponds to the span and sweep points. For higher resolution, add sweep points or reduce the span.
- (2) Press the **F2** key to select the frequency marker type as Delta.

It is used to measure the delta values of X (Frequency or Time) and Y (Amplitude) between the Reference point and certain point on the trace. When selected, a pair of markers appears on the trace, which are the Reference Marker and the Delta Marker. Will be in the active area and the display area of the upper right corner, showing the amplitude delta value between the two markers and frequency difference. If a single marker already exists, [Delta] will place a static marker and an active marker to the original position and a single marker position. Use the knob, step key, or number keys to move the marker. If there are two markers, press [Delta] directly. However, if [Delta] has been activated, press [Delta] to place the still frequency scale to the active marker. The displayed amplitude difference is expressed in dB, or is the linear unit in terms of the corresponding scale. Note:

• The Reference Marker will be activated at the position of current marker, or else both the reference marker and Delta Marker will be simultaneously activated at the center frequency location if no marker is active at the

present.

- The location of the Reference Marker is always fixed (both in the X-axis and the Y-axis), while the Delta Marker is active. You can use the direction keys to change the location of Delta Marker.
- The delta of both the Frequency/Time and the amplitude between the two markers are displayed at the corner left of the screen.
- Two ways to enable a certain point as the reference:

a) Open a "Normal" marker and locate it onto a point and then switch the marker type into "Delta", creating a new reference, then you can modify the location of the delta point to achieve the delta measurement.

b) Open a Delta Marker and place it onto a point, then reselect the Delta menu to locate the marker you opened onto this points, then you can modify the location of the delta point to achieve the delta measurement.

(3) Press the F3 key to select the frequency marker type as All.

To close the currently active cursor and its related functions, the frequency marker will no longer be displayed.

(4) Press the **F4** key to enter the next menu page, then press the **F1** key to select the frequency marker type as All Off.

To close all active cursors and their related functions, the frequency markers will no longer be displayed.

(5) Press the **F4** key to enter the next menu page, then press the **F2** key to toggle the frequency marker list between On and Off.

Turns on or off the display of all marker table.

Marker Function

Press the **F2** key to select the frequency marker function. Use the left and right arrow keys to choose the frequency marker you wish to set. Press the **F1** key to toggle the frequency marker noise on or off.

Execute the marker noise function on the selected cursor, and then read the noise power density value at the cursor position. When enabled, the average noise level displayed at the frequency marker is normalized to the noise power per 1 Hz bandwidth.

Marker->

Press the F3 key to select the Marker->. Use the left and right arrow keys to choose the marker you wish to set.

- (1) Press the F1 key to select the Marker -> Center Frequency, and set the center frequency equal to the marker frequency. This function allows you to quickly move the signal to the center of the screen.
 - When selecting the "Normal" type cursor, the center frequency is set to the frequency at the cursor position.
 - When selecting the "Delta" type cursor, the center frequency is set to the frequency at the cursor position.
 - At zero sweep width, this function is invalid.
- (2) Press the **F2** key to select the Marker-> Start Frequency, and set the spectrum analyzer's start frequency according to the frequency at the current cursor position.
 - When selecting the "Normal" type cursor, the start frequency is set to the frequency at the cursor position.
 - When selecting the "Delta" type cursor, the start frequency is set to the frequency at the cursor position.
 - At zero sweep width, this function is invalid.
- (3) Press the **F3** key to select the Marker-> Stop Frequency, and set the spectrum analyzer's stop frequency according to the frequency at the current cursor position.
 - When selecting the "Normal" type cursor, the stop frequency is set to the frequency at the cursor position.
 - When selecting the "Delta" type cursor, the stop frequency is set to the frequency at the cursor position.
 - At zero sweep width, this function is invalid.
- (4) Press the F4 key to enter the next page menu, then press the F1 key to select the Marker-> Reference Level, and set the spectrum analyzer's reference level according to the amplitude at the current cursor position.
 - When selecting the "Normal" type cursor, the reference level is set to the amplitude at the cursor position.
 - When selecting the "Delta" type cursor, the reference level is set to the amplitude at the cursor position.
- (5) Press the F4 key to enter the next page menu, then press the F2 key to select the Marker-> Sweep Width, and set the frequency sweep width equal to the frequency value of the marker. This allows the sweep width to quickly reduce as required.

Note: When selecting this function, please enable the frequency marker.

(6) Press the F4 key to enter the next page menu, then press the F3 key to select the Marker-> Center Frequency, and set the spectrum analyzer's center frequency equal to the marker frequency difference. Note: When selecting this function, please enable the frequency marker.

Peak

Press the **F4** key to enter the peak sub-menu. Then, use the left or right arrow

keys to select the frequency marker that you wish to set.

- (1) Press the **F1** key to select the maximum peak. This will place a frequency marker at the highest point of the trace, and the frequency and amplitude of this marker will be displayed in the lower left corner of the screen.
- (2) Press the **F2** key to select the peak-to-peak value. This will use the frequency marker to simultaneously find both the maximum and minimum values.
- (3) Press the **F3** key to select the next peak. This will move the active frequency marker to the next highest point on the trace, which is related to the current marker position. Pressing this key repeatedly will allow you to quickly locate lower peak points.
- (4) Press the F4 key to enter the next page menu, then press the F1 key to select the left peak. This will search for a peak to the left of the current frequency marker position. The next peak must meet the current peak and peak threshold criteria.
- (5) Press the **F4** key to enter the next page menu, then press the **F2** key to select the right peak. This will search for the next peak to the right of the current frequency marker position. The next peak must meet the current peak and peak threshold criteria.
- (6) Press the F4 key to enter the next page menu, then press the F3 key to select peak search. This allows you to set the mode for peak search, which is off by default. When enabled, the mode will automatically search for peaks.
- (7) Press the **F4** key twice to enter the third page menu, then press the **F1** key to select peak height. You can use the arrow keys to set the peak height value.
- (8) Press the F4 key twice to enter the third page menu, then press the F2 key to select search mode. You can switch between Maximum Search Mode or Minimum Search Mode.

Trigger System

Press the **F1** key to display the spectrum menu, then press the **F4** key to enter the next page menu. After that, press the **F2** key to select Trigger, which will take you to the trigger menu.

Auto

Press the **F1** key to toggle the auto trigger on or off. When the auto trigger mode is enabled, the scan trigger operates as quickly as allowed by the spectrum analyzer, ensuring that trigger conditions are met at all times and continuously generating trigger signals.

Note: Auto trigger and video trigger cannot be enabled simultaneously.

Video

Press the **F2** key to toggle the video trigger on or off. When the video trigger mode is enabled, you can modify the trigger parameters using the arrow keys. A trigger signal will be generated when the detected video signal voltage exceeds the set video trigger level.

Note: Auto trigger and video trigger cannot be enabled simultaneously.

Pre-amplifier

Press the **F1** key to display the spectrum menu, press the **F4** key to enter the next page menu, then press the **F3** key to select Pre-amplification. You can enable or disable the RF front-end amplifier switch. When measuring weak signals, turning on the pre-amplifier can reduce the displayed average noise level, making it easier to distinguish small signals from the noise.

Automatic Research

Press the **Auto** key to activate automatic search. It will automatically scan the entire frequency range for signals and adjust the frequency and amplitude parameters to optimal settings. This allows for one-touch signal search and automatic parameter adjustment.Press $\frac{Measure}{Range}$ to exit automatic research. Note: During the automatic signal search process, parameters such as reference level, scale size, input attenuation, etc., may be adjusted.

6. Communication with PC

The oscilloscope supports communications with a PC through USB. You can use the Oscilloscope communication software to store, analyze, display the data and remote control.

To learn about how to operate the software. Please download the oscilloscope communication software on our official download website and view it.

Here is how to connect with PC. Please download the Oscilloscope software package from our official website onto your computer, double-click it, and follow the prompts until the installation is complete.

- (1) **Connection:** Use a USB data cable to connect the **USB Device port** in the right panel of the Oscilloscope to the USB port of a PC.
- (2) USB Port Settings: The USB protocol type of the oscilloscope needs to be switched to HID (Press System → F4→ USB, and switch to HID).
- (3) Run the Oscilloscope software after, the connection information in the bottom right corner of the software will turn green.




Figure 6-1 Connect with PC through USB port

7. Troubleshooting

1. The oscilloscope cannot be turned on.

It may be that the battery is completely exhausted. At this time, even if the oscilloscope is powered by the power adapter, the oscilloscope cannot be turned on. You need to charge the battery first, and do not turn on the oscilloscope. Wait for about 15 minutes, and then try to turn on the oscilloscope. If the oscilloscope still cannot be turned on, please contact us to serve you.

2. The oscilloscope turns off after a few seconds of startup.

It may be that the battery is exhausted. Check the battery symbol at the top left of the screen.

symbol indicates that the battery is exhausted and must be charged.

3. After switching to the multimeter, the measurement type is displayed as E.

It may be that the measurement type was not selected. At this time, press **F4**, the measurement type should display the corresponding measurement type. If E is still displayed, restart the oscilloscope.

4. In the oscilloscope state, the measured voltage amplitude value is 10 times larger or smaller than the actual value.

Check whether the channel attenuation coefficient is consistent with the actual probe error ratio.

5. In the oscilloscope state, there is a waveform display, but it cannot be stabilized.

- Check whether the source item in the trigger mode menu is consistent with the signal channel actually used.
- Check whether the trigger electrical level has exceeded the waveform range. Only by setting the parameters reasonably, the waveform can be displayed stably.
- 6. In the oscilloscope state, nothing is displayed after pressing

RUN/STOP.

Check whether the trigger mode of the trigger mode menu is normal or single, and the trigger electrical level is out of the waveform range. If so, center the trigger electrical level or set the trigger mode to automatic. In addition, you can press **Auto** to automatically complete the above settings.

7. In the oscilloscope state, the display speed becomes slower when the average value sampling is set in the acquisition mode or the duration is set longer in the display settings.

It is normal.

8. Technical Specifications

Unless otherwise stated, all technical specifications are applicable to the probe with the attenuation switch set to 10X and this series of oscilloscopes. The oscilloscope must first meet the following two conditions to meet these specifications and standards:

The instrument must be operated continuously for more than 30 minutes at the specified operating temperature.

■ If the operating temperature variation range reaches or exceeds 5 °C , the system function menu must be opened to execute the "automatic correction" program (see automatic correction in "System Settings" on P18).

All specifications are guaranteed except those marked "typical".

Characteristics			Description
Verti	cal resolution	8 bits	
	Channel	2	
	Sampling method	Sampling, pe	eak detection
		HSA2307	125 MSa/s (Dual Channel) 250 MSa/s (Single Channel)
Sampling	Real-time sampling rate	HSA2310	250 MSa/s (Dual Channel) 500 MSa/s (Single Channel)
		HSA2320	1 GSa/s
	Waveform refresh rate	10,000 wfms/s	
	Input coupling	DC, AC, ground	
	Input impedance (DC coupling)	1 M Ω ±2%, in parallel with 16 pF±10 pF	
Input	Probe attenuation	1X , 10X, 100X, 1000X , 10000X	
	Maximum input voltage	t 400 V (DC + AC ,PK - PK)	
	Bandwidth limit	20 MHz, Full bandwidth	

Oscilloscope

Cha	racteristics		Description
	Sampling rate range	0.25 Sa/s~2	•
	Waveform interpolation	(Sinx)/x	
Horizontal	Sweep speed range	HSA2307	5ns/div - 1000s/div,Stepping in the 1-2-5 way
	(S/div)	HSA2310 HSA2320	2ns/div - 1000s/div,Stepping in the 1-2-5 way
	Time base accuracy	±100 ppm	
	Record length	8K or 4K opt	ional
	Sensitivity	10 mV/div \sim	10.)//div
	(Volt/div) range		
	Displacement range	HSA2307 HSA2310	±6 div
		HSA2320	±2 V (10 mV/div – 200 mV/div); ±100 V (500 mV/div – 10V/div)
	Analog bandwidth	HSA2307	70 MHz
		HSA2310	100 MHz
Vertical	Single bandwidth	HSA2320 Full bandwidt	200 MHz
	Low frequency		
		≥10 Hz	
	response		
	(AC coupling, -3dB)		≤ 5 ns
	Rise time	HSA2307	≤ 3.5 ns
	(typical on BNC)	HSA2310 HSA2320	≤ 1.75 ns
	DC gain accuracy	3%	
	Cursor	ΔV, ΔΤ	
Measurement	Automatic	Period, Frequency, Mean, PK-PK, Max, Min, Amplitude, RMS,Rise Time,Fall Time, +PulseWidth, -PulseWidth	
	Source	CH1, CH2	
Triggering	Туре	Edge	
	Coupling	DC, AC	
	Trigger type	Auto, normal, single	

Chara	Characteristics		Description
	Frigger ele evel range	ectrical	±4 div from the center of the screen
	Frigger ele evel accuracy	ectrical	±0.3 div
Т	Frigger displac	cement	According to Record length and time base
E	Edge	Slope	Rising edge, falling edge
tr	riggering	Clope	

The output of the probe compensator:

Characteristics	Description
Output voltage (typical)	3.3Vpp, High-Z
Frequency (typical)	Square wave 1 kHz (±1%)

Multimeter

Characteristics	Description
Digital display	20,000 readings
Measurement type	Voltage, current, resistance, capacitance, on/off, diode
Maximum Input voltage	AC : 750V DC : 1000V
Maximum Input current	AC : 10A DC : 10A

Basic function	Range	Minimum resolution	Accuracy
	20.000mV	0.001mV	±(0.5%+15dig)
	200.00mV	0.01mV	±(0.3%+10dig)
DC voltage	2.0000V	0.1mV	
	20.000V	1mV	
	200.00V	0.01V	±(0.3%+5dig)
	1000.0V	0.1V	
AC voltage ^[1]	20.000mV	0.001mV	
	200.00mV	0.01mV	
	2.0000V	0.1mV	±(0.8%+10dig)
	20.000V	1mV	
	200.00V	0.01V	
	750.0V	0.1V	±(1.0%+10dig)

Basic function	Range	Minimum	Accuracy
	Frequency range	resolution : 40Hz-1000H	7
	20.000mA	0.001mA	±(1.0%+10dig)
	200.00mA	0.00 mix	±(0.8%+10dig)
	2.0000A	0.0001A	
DC current	10.000A	1mA	±(2.5%+10dig)
	Overload protection		1
	mA function: self-	healing fuse 4	00 mA/250 V; Ampere function: 10
	A/600 V, D5.2*20	, fast-acting fu	se
	20.000mA	0.001mA	±(1.2%+10dig)
	200.00mA	0.01mA	±(1.0%+10dig)
	2.0000A	0.0001A	
AC current ^[1]	10.000A	1mA	±(2.8%+10dig)
	Frequency range	: 40Hz-1000H	Z
	Overload protection	on:	
		0	00 mA/250 V; Ampere function: 10
	A/600 V, D5.2*20	, , , , , , , , , , , , , , , , , , ,	
	200.00Ω	0.01Ω	±(0.8%+10dig)
	2.0000kΩ	0.1Ω	±(0.8%+5dig)
	20.000kΩ	1Ω	_
Resistance	200.00kΩ	10Ω	±(0.8%+3dig)
	2.0000ΜΩ	0.1kΩ	
	20.000ΜΩ	1kΩ	±(1.0%+3dig)
	100.00MΩ	0.01MΩ	±(5.0%+10dig)
	2.000nF	1pF	
	20.00nF	10pF	
	200.0nF	100pF	
Capacitance ^[1]	2.000µF	1nF	±(3.0%+10dig)
	20.00µF	10nF	
	200.0µF	100nF	
	2.000mF	1uF	
	On/Off test	√ (<50Ω)	
	Diode test	√(<0-2V)	
Others	Auto range	\checkmark	
	TRMS	\checkmark	

[1] : When measuring AC voltage/current or capacitance, accuracy

guarantee range is 5% to 100% of the range.

Spectrum

Characteristics	Description		
Frequency			
Range	9 kHz to 3.0 GHz		
Resolution	1 Hz		
Frequency Spar	ו		
Range	Zero span, 300 Hz to maximum bandwidth		
Uncertainty	± Span / (number of sweep points -1)		
Bandwidth			
Resolution Bandwidth	0.2, 1, 3, 10, 30, 100, 300, 600, 850 kHz		
Max. Input Leve			
Input DC	50V		
Continuous	Attenuator= 30 dB		
power	+20 dBm (100 mW)		
Max. damage level	+20 dBm (100 mW)		
Display Average	Noise Level (DANL)		
Frequency	(attenuation = 0 dB, RBW = VBW = 100 Hz, sample detector, trace average \geq 50, 20°C to 30°C, input impendence = 50 Ω)		
	10MHz to 1 GHz <-120 dBm		
Preamp Off	1 GHz to 2 GHz <-120 dBm		
	2 GHz to 3 GHz <-115 dBm		
	10MHz to 1 GHz <-140 dBm		
Preamp On	1 GHz to 2 GHz <-140 dBm		
	2 GHz to 3 GHz <-135 dBm		
Level display			
Logarithmic level	0.01 dB to 99 dB		
Linear level	0 to reference level		
Number of display points	301		
Number of traces	1		
Units	dBm, dBmV, dBµV, W, V		
Input attenuation			
Setting range	0 dB to 30 dB, step by 1 dB		
Switching	fc= 50 MHz, relative to 10 dB, 20° C to 30° C		
uncertainty	<2.5 dB		

$ \begin{array}{ c c c c } Absolute Amplitude Uncertainty & fc = 50 MHz, peak detector, preamplifier off, attenuation = 10 dB, input signal level = -10dBm, 20°C to 30°C & <1.5 dB & \\ \hline \begin{tumbbraic}{ c c c c c } \hline \begin{tumbbraic}{ c c c c } c = 50 MHz, peak detector, preamplifier off, attenuation = 10 dB, input signal level = -10dBm, 20°C to 30°C & \\ \hline \begin{tumbraic}{ c c c c } c = 50 MHz, peak detector, preamplifier off, attenuation = 10 dB, input signal level = -10dBm, 20°C to 30°C & \\ \hline \begin{tumbraic}{ c c c c } c = 10 MHz, pack detector, preamplifier off, attenuation = 10 dB, respective to 10 MHz RBW & \\ \hline \begin{tumbraic}{ c c c c c c } c = 10 MB, step by 1 dB & \\ \hline \begin{tumbraic}{ c c c c c } respective to 10 dB (typical value) & \\ \hline \begin{tumbraic}{ c c c c c } c = 10 dB, respective to 0 B, RBW = VBW = 1 & \\ \hline \begin{tumbraic}{ c c c c c } c = 10 dB, respective to 30°C & \\ \hline \begin{tumbraic}{ c c c c c } c = 10 dB, respective to 30°C & \\ \hline \begin{tumbraic}{ c c c c c } c = 10 dB, respective to 30°C & \\ \hline \begin{tumbraic}{ c c c c c } c = 10 dB, respective to 30°C & \\ \hline \begin{tumbraic}{ c c c c c c } c = 10 dB, respective to 30°C & \\ \hline \begin{tumbraic}{ c c c c c c } c = 10 dB, respective to 30°C & \\ \hline \begin{tumbraic}{ c c c c c c c } c = 10 dB, respective to 30°C & \\ \hline \begin{tumbraic}{ c c c c c c c } c = 10 dB, respective to 30°C & \\ \hline \begin{tumbraic}{ c c c c c c c } c = 10 dB, respective to 30°C & \\ \hline \begin{tumbraic}{ c c c c c c c c } c = 10 dB, respective to 30°C & \\ \hline \begin{tumbraic}{ c c c c c c c } c = 10 dB, respective to 30°C & \\ \hline \begin{tumbraic}{ c c c c c c c } c = 10 dB, respective to 30°C & load, with attenuator set to 0 & \\ \hline \begin{tumbraic}{ c c c c c c c } c = 10 dB, respective to 30°C & \\ \hline \begin{tumbraic}{ c c c c c c c c c } respective to 30°C & \\ \hline \begin{tumbraic}{ c c c c c c c c c c c } respective to 30°C & \\ \hline \begin{tumbraic}{ c c c c c c c c c c c c c c c c c c $					
$\begin{tabular}{ c c c c } \hline Uncertainty & signal level = -10dBm, 20 °C to 30 °C \\ \hline <1.5 dB & \hline \\ \hline & $<1.5 dB & \hline \\ \hline & $$ $$ $$ $$ $$ $$ $$ $$ $$ $$ $$ $$ $$	Absolute	e Amplit	ude Uncertainty		
$ \hline < 1.5 dB \\ \hline \hline < 1.5 dB \\ \hline \hline \\ \hline $	Uncertainty				
$\begin{array}{ c c c c } \hline RBW Switching Uncertainty & relative to 10 kHz RBW \\ \hline eq:spectral_sp$			signal level = -10dBm, 20 $^\circ C$ to 30 $^\circ C$		
$\begin{tabular}{ c c c c } \hline \mbox{relative to 10 kHz RBW} & \end{tabular} \\ \hline \mbox{relative to 10 kHz RBW} & \end{tabular} \\ \hline \mbox{scheme} & \end{tabular} \\ \hline \mbox{relative to 10 kHz RBW} & \end{tabular} \\ \hline \end{tabular} \\ \hline \mbox{Reference level} & \end{tabular} \\ \hline \mbox{Range} & \end{tabular} & \end{tabular} \\ \hline \mbox{Resultants} \\ \hline \mbox{Residual} & \end{tabular} \\ \hline \mbox{Result abular} \\ \hline \mbox{Residual} & \end{tabular} \\ \hline \mbox{Residual} \\ $			<1.5 dB		
Uncertainty <2.0dB	RBW Sv	witching	Uncertainty		
$\begin{tabular}{ c c c c } \hline c c c c c c c c c c c c c c c c c c $	Uncerta	intv	relative to 10 kHz RBW		
Range-80dBm to +20 dBm, step by 1 dBPre-amplifier20 dB (typical value)Level Measurement Uncertainty (95% confidence level, S/N > 20 dB, RBW = VBW = 1kHz, preamplifier off, attenuation = 10 dB, -50 dBm < input level \leq 0 dBm, fc > 10 MHz,20°C to 30°C)0Uncertainty<2.0 dB					
Pre-amplifierGain20 dB (typical value)Level Measurement Uncertainty (95% confidence level, S/N > 20 dB, RBW = VBW = 1kHz, preamplifier off, attenuation = 10 dB, -50 dBm < input level \leq 0 dBm, fc > 10 MHz,20°C to 30°C)UncertaintyUncertainty<2.0 dB	Referen	ce level			
Gain20 dB (typical value)Level Measurement Uncertainty (95% confidence level, S/N > 20 dB, RBW = VBW = 1kHz, preamplifier off, attenuation = 10 dB, -50 dBm < input level \leq 0 dBm, fc > 10 MHz,20°C to 30° C)Uncertainty<2.0 dB	Range		-80dBm to +20 dBm, step by 1 dB		
Level Measurement Uncertainty (95% confidence level, S/N > 20 dB, RBW = VBW = 1 kHz, preamplifier off, attenuation = 10 dB, -50 dBm < input level \leq 0 dBm, fc > 10 MHz, 20°C to 30°C)Uncertainty<2.0 dB	Pre-amp	olifier			
kHz, preamplifier off, attenuation = 10 dB, -50 dBm < input level \leq 0 dBm, fc > 10 MHz, 20°C to 30°C)20°C to 30°C)Uncertainty<2.0 dB	_				
$ \begin{array}{ c c } \label{eq:constraint} eq$					
$\begin{array}{ c c c } RF input VSWR & (Attenuator setting \geq 10 dB) \\ \hline VSWR & < 2.0 \\ \hline Spurious \\ \hline VSWR & < 2.0 \\ \hline Spurious \\ \hline Spurious \\ \hline Spurious \\ response & \hline The input ports is connected to a 50 \Omega load,with attenuator set to 0 dB, 20^{\circ}C to 30^{\circ}C \\ \hline <-90 dBm, typical \\ \hline IF \\ feedthrough \\ Input-related \\ spurious \\ signals & \hline The mixer level is -30 dBm \\ \hline Connector \\ \hline RF \\ Input & \hline Conne \\ \hline RF \\ Input & \hline Conne \\ \hline SMA female connector \\ \hline \end{array}$	20 ℃ to	30℃)			
$\begin{array}{ c c c } \hline VSWR & < 2.0 \\ \hline Spurious \\ \hline Residual \\ response & \hline The input ports is connected to a 50 Ω load,with attenuator set to 0 \\ \hline dB, 20°C to 30°C \\ \hline <-90 \ dBm, typical \\ \hline IF \\ feedthrough & < -60 \ dBc \\ \hline Input-related \\ spurious \\ signals & \hline The mixer level is -30 \ dBm \\ \hline <-50 \ dBc \\ \hline \hline Connector \\ \hline RF \\ \hline Input & \hline Conne \\ \hline RF \\ \hline Input & \hline Conne \\ \hline SMA female connector \\ \hline \end{array}$	Uncertainty <2.0 dB		<2.0 dB		
$\begin{array}{ c c c } \hline Spurious & \hline \\ \hline Spurious & \hline \\ \hline Residual response & \hline \\ \hline IF & \\ feedthrough & \hline \\ Input-related spurious & \\ signals & \hline \\ \hline \\ RF & \hline \\ Input & \hline \\ RF & \hline \\ Input & \hline \\ \hline \\ RF & \hline \\ Input & \hline \\ \hline \\ Conne & \hline \\ \hline \\ Conne & \hline \\ \hline \\ SMA female connector & \hline \\ \hline$	RF inpu	t VSWR	(Attenuator setting≥ 10 dB)		
$\begin{array}{ c c c c c } \hline Residual \\ response \end{array} & \begin{array}{ c c c c } \hline The input ports is connected to a 50 \ \Omega \ load, with attenuator set to 0 \\ \hline dB, 20 \ C \ to 30 \ C \\ \hline < -90 \ dBm, typical \end{array} \\ \hline < -90 \ dBm, typical \end{array} \\ \hline \\ \hline \\ response \end{array} & \begin{array}{ c } \hline \\ response \end{array} & \begin{array}{ c } \hline \\ < -60 \ dBc \end{array} \\ \hline \\ \hline \\ response \end{array} & \begin{array}{ c } \hline \\ \hline \\ \hline \\ response \end{array} & \begin{array}{ c } \hline \\ \hline \\ \hline \\ response \end{array} & \begin{array}{ c } \hline \\ \hline \\ \hline \\ \hline \\ response \end{array} & \begin{array}{ c } \hline \\ \hline \\ \hline \\ \hline \\ response \end{array} & \begin{array}{ c } \hline \\ \hline \\ \hline \\ \hline \\ \hline \\ response \end{array} & \begin{array}{ c } \hline \\ \hline \\ \hline \\ \hline \\ \hline \\ response \end{array} & \begin{array}{ c } \hline \\ \hline $	VSWR	VSWR < 2.0			
Residual responsedB, 20°C to 30°C < -90 dBm, typicalIF feedthrough< -60 dBc	Spuriou	S			
$ F < -90 \text{ dBm, typical} \\ F < -60 \text{ dBc} \\ \text{feedthrough} \\ \text{Input-related spurious signals} \\ \text{Solution} \\ \text{Solution} \\ \text{Connector} \\ \text{Imped ance ance} \\ \text{Solution} \\ Soluti$	Residual				
feedthrough < -60 dBc	respon	se	< -90 dBm, typical		
spurious signals < -50 dBc			< -60 dBc		
signals < -50 dBc	Input-related		The mixer level is -30 dBm		
Imped ance 50 Ω, typical Input Conne SMA female connector	•		< -50 dBc		
RF ance SMA female connector	Connec	tor			
SMA female connector	RF		50 Ω, typical		
			SMA female connector		

General Technical Specifications

Display

Characteristics	Description	
Display type	3.5-inch color LCD display	
Display resolution	320 horizontal × 240 vertical pixels	
Display color	65536 colors	
Display Contrast	Adjustable	

Power supply

Characteristics	Description			
Power supply	DC INPUT: 5V	DC INPUT: 5VDC, 2A		
Power	HSA2307	<5 W		
consumption	HSA2310	< 3 VV		
	HSA2320	<6 W		
Battery	HSA2307	2200mAh*2 (3.7V, 18650)		
	HSA2310	2600mAh*2 (3.7V, 18650)		
	HSA2320	2000IIIAII 2 (3.7V, 18050)		

Surroundings

Characteristics	Description
Tomporaturo	Working temperature: 0° C - 40° C
Temperature	Storage temperature: -20℃- +60℃
Relative humidity	≤90%
Hoight	Operating: 3,000 meters
Height	Non-operating: 15,000 meters
Cooling method	Natural cooling

Mechanical specifications

Characteristics	Description	
Dimensions	198 mm (length) × 96mm (height) × 38 mm (width)	
Weight	About 0.6 kg (main unit, without battery)	

Calibration interval: The recommended calibration interval is one year.

9. Appendix

Appendix A: List of Accessories

- 1 USB cable
- A set of passive probes (2 pieces)
- 1 set of multimeter probes (one red and one black)
- 1 Quick Guide

Appendix B: Maintenance and Cleaning

General maintenance

Do not store or place the instrument in a place where the LCD screen will be exposed to direct sunlight for a long time.

Caution: Do not let spray, liquid or solvent touch the instrument or probe to prevent damage to the instrument or probe.

Cleaning:

Check the instrument and probe frequently according to the operation. Clean the external surface of the instrument as follows:

1. Please wipe the floating dust outside the instrument and probe with a soft cloth. When cleaning the LCD, be careful not to scratch the transparent LCD protection screen.

2. Wipe the instrument with a damp but non dripping soft cloth. Please disconnect the power supply. It can be scrubbed with soft detergent or water. Do not use any abrasive chemical cleaning agent to avoid damaging the instrument or probe.

Warning: Please make sure the instrument is dry before re-energizing to avoid electrical short circuit or personal injury caused by moisture.

Charging and Replacement of Battery

During the long-term storage of the device, the battery may be too low due to the self-discharge of the lithium battery and the device cannot be turned on. This is a normal phenomenon.

Please use the attached adapter to pre-charge the device for 0.5 to 1 hour (d epending on the storage time) before turning it on. In addition, if the device is not used for a long time, it is recommended to charge it at regular intervals t o avoid over-discharge of the lithium battery.

Battery Charging

The lithium battery may not be fully charged when delivered. To make the battery be charged, refer to the following table to charge and discharge:

Model	Charging	Discharging
For models<100MHz	≥4.5h	≥4h
For models≥100MHz	≥4h	≥3h

The power supply and battery indicator symbols in the upper right corner of the screen are explained as follows:

symbol indicates the power-on charging status;

symbol indicates battery power supply;

symbol indicates that there is only about five minutes of use time left. Please charge as soon as possible according to the relevant tips to avoid damage to the battery.

Charging Method

Charging the battery through the power adapter: Connect the oscilloscope to the power socket through the USB data cable and power adapter delivered with the machine for charging.

Charge the oscilloscope through the USB interface: Connect the oscilloscope to a computer or other equipment through a USB data cable for charging (pay attention to the load capacity of the power supply equipment to avoid abnormal operation of the equipment).

Note

To avoid overheating of the battery during charging, the ambient temperature must not exceed the allowable value given in the technical specifications.

Replacement of Lithium Battery

Generally, the battery does not need to be replaced. However, when necessary, it can only be replaced by qualified personnel, and only **lithium batteries of the same specification** can be used.